
## Gleam Recessed LED Downlight Installation Instructions

ΗΔ/ΙΤ



- Fitting is preset to 3000k, to change slide switch on back of fitting to desired colour temperature. 4.
- If HV5528-ICCAP is being used, Clip onto back of fitting. 5.
- 6. Pull back springs on fitting and insert into hole.
- Once fitting is in hole, release clips onto back of ceiling, These springs will hold fitting in place. 7.
- 8. All connections must be carried out carefully, inspect all contacts before switching back on the electric circuit.
- 9. If a dimmer is being used, Refer to dimmer instructions for connection method.

## Must be installed by a licensed electrician

Contact Details:		Warranty Terms & Conditions*	www.havit.com.au
143 Beauchamp Road Matraville NSW 2036 Australia	Tel: 02 9381 8300 Fax: 02 9666 8881 Email: sales@havit.com.au Web: www.havit.com.au		