



# HV8028C/W-BLK Installation Instructions



PRODUCT SPECIFICATIONS	
Model No.	HV8028C-BLK, HV8028W-BLK
Name	Concept
Material	Aluminium
Colour	Black with gold insert
IP Rating	IP20
Input Voltage	240V
Lamp Base	G9
Lamp Wattage	2w
CRI:	>80
Wiring	Parallel
Dimmable	No
Warranty	2 Years Replacement



## Important Safety Issues:

- This product must be installed by a qualified electrician according to AS/NZS 3000.
- Ensure all electrical mains are disconnected before any installation.
- Do not exceed maximum wattage restrictions for globes: 240V GU10 = 35w / 12V MR16 = 20w
- Modification of this product will void any warranty.
- Havit Lighting does not take responsibility for wrong installation, incorrect use, or use of installation material that does not belong to the system.
- When installing low voltage fittings, Voltage to fitting must be within +or- 5% of voltage required, if not within this allowance warranty will be voided.
- Aluminium and 304SS fittings must not be installed within 2km of any salt water environments.
- When installing copper fittings, gloves must be worn to avoid any oils transferring to fitting.
- All 316 stainless steel fittings must have regular cleaning maintenance to avoid any tea staining from forming on fitting. (Warranty does not cover Tea Staining)
- All o-rings and seals must be in place correctly to maintain warranty.

## Steps for Installation:

1. Make sure that the electrical circuit is free of voltage (master switch off).
2. Remove the fitting from backing plate by undoing the screws.
3. Install backing plate securely.
4. Connect the cable using wire with earth. Connect earth first, then live and neutral wires.
5. Affix the face of the fitting to the backing plate, making sure screws are tight.
6. Insert globe provided.
7. All connections must be carried out carefully, inspect all contacts before switching back on the electric circuit.

## Steps for Changing Globe:

1. Ensure light is switched off.
2. Remove the globe from the lampholder by pulling gently.
3. Taking care not to touch the bulb of the globe, insert the new globe by holding at the base and gently pushing the 2 pins into the lamp holder until firmly in place.
4. Make sure not to exceed max wattage, see product label for correct info.

## Must be Installed by a Licensed Electrician

For More Information Contact Havit Lighting

143 Beauchamp Road  
Matraville NSW 2036  
Australia

Tel: 02 9381 8300  
Fax: 02 9666 8881  
Email: sales@havit.com.au  
Web: www.havit.com.au