

# Veko Wall Light with Eyelid Installation Instructions



#### Dimensions

Mounting Base

HAVIT



## Important Safety Issues:

- This product must be installed by a qualified electrician according to AS/NZS 3000.
- Ensure all electrical mains are disconnected before any installation.
- Modification of this product will void any warranty.
- Havit Lighting does not take responsibility for wrong installation, incorrect use, or use of installation material that does not belong to the system.
- When installing low voltage fittings, Voltage to fitting must be within +or- 5% of voltage required and cannot be installed more than 25m from LED Driver, if not within this allowance warranty will be voided.
- Aluminium and 304SS fittings must not be installed within 5km of any salt water environments.
- When installing Brass fittings, gloves must be worn to avoid any oils transferring to fitting.
- All 316 stainless steel fittings must have regular cleaning maintenance to avoid any tea staining from forming on fitting. (Warranty does not cover Tea Staining)
- · All o-rings and seals must be in place correctly to maintain warranty.
- These instructions may be updated at any time due to product improvements, Please visit website for most current installation instructions.

### **Steps for Installation:**

- 1. Make sure that the electrical circuit is free of voltage (master switch off)
- 2. Loosen or remove allen screws from side of fitting as set aside if removed.
- 3. 240v Model Use wire with earth.
- 4. 12v DC Models Using an appropriate 12v DC Constant Voltage LED Driver DO NOT CONNECT LIGHT FITTING DIRECTLY TO 240V.
- 5. Strip back the cable on both fitting and cable run and (for 240v Models twist the earth cables together first) twist the positive cables together. Then connect neutral cables together.
- 6. For 12v Models, If more than one fitting installed, wiring must be done in parallel.
- 7. Solder all joins using solder and either a heat gun or butane gas torch.
- 8. Cover connections using an adhesive lined heat shrink or gel cap to make connection watertight. Failure to do this will void warranty.
- 9. Heat the heat shrink or crimp the gel cap making sure all connections are covered.
- 10. Install base plate in desired location, Seal all holes in the backing plate including cable entry and screw holes.
- 11. Fitting is preset to 3000k, To change move switch located inside fitting to desired colour temperature.
- 12. Reattach face onto fitting making sure seals are still in place
- 13. Reinsert allen screws if removed and tighten making sure seals are still in place to avoid water penetration into fitting.
- 14. Apply silicon around edge of fitting to prevent any water from getting inside to electrical connections
- 15. All connections must be carried out carefully, inspect all contacts before switching back on the electric circuit.

## Must be installed by a licensed electrician

Contact Details:		Warranty Terms & Conditions*	www.havit.com.au
143 Beauchamp Road Matraville NSW 2036 Australia	Tel: 02 9381 8300 Fax: 02 9666 8881 Email: sales@havit.com.au Web: www.havit.com.au		